



Step 1.
Remove Doors Front and Rear



Step 6.
Remove One Rear Column Cover By Un-doing Screws



Step 2.
Undo Shelf Light Fittings



Step 7.
Remove Rubber In Fill At Back Of Glass End Panel



Step 3.
Remove All Shelves



Step 8.
Slide End Glass Back To Release And Remove



Step 4.
Remove Deck Trays



Step 9.
Position Front Glass Through The Side



Step 5.
Remove One End Trim By Un-doing Screws



Step 10.
Line Glass Up And Lift Up Into Front Door Track. The Rollers On The Solid Front Will Locate Onto The Bottom Track



Larger Pieces Will Require Two People



Step 13. Replace Deck Trays And Reposition Shelves.



Note: Shelves Need To Go In Through The End



Step 11. Glass in place - Position With Equal Gap At Each End



Step 14. Reassemble.
 1 - End Glass Panel In-Slide Forward
 2 - Rubber Trim Down Edge Of Glass
 3 - Install Rear Column Cover
 4 - Install End Trim



Step 12. Fit Rubber Trim (Supplied) To Front To Secure Glass



Step 15. JOB COMPLETE