



BTR-15 Part List

Part No	Name	Qty
S16-485	COMPRESSOR	1
S16-463	CONDENSER	1
S16-151	FAN/MOTOR COVER	2
S16-487	EVAPORATOR	1
S02-019	BLOWER	5
S16-040	THERMOSTAT	1
S16-452	CIRCUIT BREAKER	1
S16-388	TERMINAL BLOCK	3
S16-465	LAMP	2
S16-482	LAMP	1
S16-466	STARTER	3
S16-467	LAMP HOLDER	3
S16-480	LAMP CLIP	6
S16-468	BALLAST	2
S16-220	PLASTIC CONTAINER	1
S21-005	ROLLER GUIDE	2
S21-076	S21-006 ALUM SEAL (SET)	2
S21-073	GLASS FRAME, REAR	2
S21-049	ROLLER	8
S21-023	DOOR ASSY, REAR	2
S21-013	RUBBER SEAL	3
S21-066	SIDE GLASS	2
S21-079	GLASS PANEL, FRONT	1
S25-052	WIRE SHELF	6
S25-053	WIRE SHELF	9
S16-061	FILTER	1
S99-237	DRAIN ASSY	1
A34001	TICKET STRIPS	3
X000284	DECK TRAYS	2
S19-148	CASTOR CW/BREAK	2
S19-149	CASTOR	2
A50019	SIDE PLATE	2
A50014	FRONT SHUTTER	1
A50013	REAR PLATE	1
A34019	Ticket strips of deck	2