


F90-713



C4ABC9 Part list

Part No	Name	Qty
S16-566	BLOWER	1
S16-388	TERMINAL BLOCK	3
S16-465	LAMP	4
S16-466	STARTER	4
S16-467	LAMP HOLDER	4
S16-480	LAMP CLIP	8
S16-468	BALLAST	4
S16-469	CONNECTOR, 3-PIN	4
S19-008	RUBBER FOOTING	4
S19-027	LEG, TUBULAR	4
S21-027	ROLLER GUIDE	2
	S99-180 DOOR HANDLE, REAR GLASS	2
F90-335	S21-028 GLASS FRAME	2
(left)	S21-055 GLASS PANEL, REAR	2
F90-360	S19-326 ROLLER	4
(right)	S21-015 PVC STOPPER	3
	S21-013 RUBBER SEAL	2
	S99-007 SEAL	4
A56008	Ticket strips of deck	1
S21-020	SIDE GLASS LEFT	1
S21-021	SIDE GLASS RIGHT	1
	S21-052 GLASS PANEL, FRONT	2
	S21-012 DOOR HANDLE, FRONT GLASS	2
F90-333	S21-013 RUBBER SEAL	2
(left)	S21-013 RUBBER SEAL	4
	S19-326 ROLLER	4
F90-359	S21-015 PVC STOPPER	3
(right)	S99-007 SEAL	4
	S21-028 GLASS FRAME	2
S25-048	WIRE SHELF, UPPER	2
S25-050	WIRE SHELF, UPPER	1
S25-049	WIRE SHELF, LOWER	2
S25-051	WIRE SHELF, LOWER	1
S25-052	WIRE SHELF, MID	2
S25-053	WIRE SHELF, MID	1
S16-571	CEILING FAN	1