



C4HT9 Part list

Part No	Name	Qty
S16-491	HEATER	1
S16-043	BLOWER	3
S16-470	THERMOSTAT	1
S16-452	CIRCUIT BREAKER	1
S16-388	TERMINAL BLOCK	3
S16-465	LAMP	3
S16-466	STARTER	3
S16-467	LAMP HOLDER	3
S16-480	LAMP CLIP	6
S16-468	BALLAST	3
S16-469	CONNECTOR 3-PIN	2
S19-008	RUBBER FOOTING	4
S19-027	LEG, TUBULAR	4
S21-027	ROLLER GUIDE	2
S99-180	DOOR HANDLE, REAR GLASS	2
S21-028	GLASS FRAME	2
S21-055	GLASS PANEL, REAR	2
S21-037	ROLLER	4
S21-015	PVC STOPPER	3
S21-013	RUBBER SEAL	2
S99-407	SEAL	4
A20049	Ticket strips of deck	2
S21-021	SIDE GLASS	2
S21-052	GLASS PANEL, FRONT	2
S16-055	DOOR HANDLE, FRONT GLASS	2
S21-012	RUBBER SEAL	2
S21-050	ROLLER	4
S21-015	PVC STOPPER	3
S99-407	SEAL	4
S21-028	GLASS FRAME	2
S25-048	WIRE SHELF, UPPER	2
S25-052	WIRE SHELF, MID	2
S25-049	WIRE SHELF, LOWER	2
S25-050	WIRE SHELF, UPPER	1
S25-053	WIRE SHELF, MID	1
S25-051	WIRE SHELF, LOWER	1
X000274	BOTTOM BRANDING PANEL	1
A20031	TICKET STRIPS	2
A20032	TOP BRANDING PANEL	1